



NOTES:

- CONCRETE PAD TO BE POURED INDEPENDENT OF OTHER CONCRETE WORK.
- CONTACT CITRUS HEIGHTS WATER DISTRICT FOR REBAR INSPECTION PRIOR TO POURING CONCRETE. (916) 725-6873
- MATERIAL BELOW AGGREGATE BASE SHALL BE COMPACTED TO 90% MINIMUM.
- REINFORCED CONCRETE PAD SHALL BE FINISHED WITH AN EDGING TOOL AROUND THE ENTIRE PERIMETER AND BROOMED AT RIGHT ANGLES TO THE DIRECTION OF TRAVEL.
- PAINT FIRE HYDRANT USING A RUSTOLEUM RECOMMENDED PRIMER, FINISH WITH RUSTOLEUM GLOSS WHITE, TWO COATS MINIMUM. PRIOR TO PAINTING, CLEAN ALL SURFACES WITH SOAP AND WATER USING AN ABRASIVE PAD.

1	REINFORCED CONCRETE PAD - TYPE II SIX-SACK PORTLAND CEMENT	4	3/4" CLASS 2 AGGREGATE BASE - 2" MINIMUM, MECHANICALLY COMPACTED TO 90%
2	3/8" (#3) REBAR - 2" INSIDE PERIMETER		
3	CONCRETE DOBIE w/ WIRE	5	ASPHALT SATURATED ORGANIC FELT (ROOFING PAPER) - ASTM 30, 2 LAYERS AROUND FIRE HYDRANT



**CITRUS
HEIGHTS
WATER
DISTRICT**

FIRE HYDRANT ACCESS PAD

CITRUS HEIGHTS WATER DISTRICT

APPROVED BY: Robert A. Chumblee DATE: 5/8/13
CITRUS HEIGHTS WATER DISTRICT

DRAWN: 8 MAY 2013

REVISED:

SCALE: N.T.S.

DESIGN: P.A.D.

CAD FILE: FH_683.DWG

PAGE:

FH_683